

Drum en tonercartridges voor all-in-one zwart-witlaserprinters DCP / MFC



	TN-200 / DR-200	TN-1050 / DR-1050	TN-2000 / DR-2000	TN-2110 / DR-2100	TN-2120 / DR-2100	TN-2010 / DR-2200	TN-2210 / DR-2200	TN-2220 / DR-2200	TN-2310 / DR-2300	TN-2320 / DR-2300	TN-3030 / DR-3000	TN-3060 / DR-3000	TN-3130 / DR-3100	TN-3170 / DR-3100	TN-3230 / DR-3200	TN-3280 / DR-3200	TN-3330 / DR-3300	TN-3380 / DR-3300	TN-3390 / DR-3300	TN-3430 / DR-3400	TN-3480 / DR-3400	TN-3512 / DR-3400	TN-3520 / DR-3400	TN-6300 / DR-6000	TN-6600 / DR-6000	TN-7300 / DR-7000	TN-7600 / DR-7000	TN-8000 / DR-8000
All-in-one zwart-witlaserprinters DCP				HY			HY		HY		HY		HY		HY		HY	SHY		HY	SHY	UHY		HY		HY		
DCP-1510 / 1610W / 1612W		•																										
DCP-7010 / 7025			•																									
DCP-7030 / 7040 / 7045N				•	•																							
DCP-7055						•																						
DCP-7060D / 7065DN / 7070DW							•	•																				
DCP-8020 / 8025DN																										•	•	
DCP-8040 / 8045DN											•	•																
DCP-8060 / 8065DN													•	•														
DCP-8070D / 8085DN															•	•												
DCP-8110DN																	•	•										
DCP-8250DN																	•	•	•									
DCP-L2500D / L2520DW / L2540DN / L2560DW										•	•																	
DCP-L5500DN																				•	•							
DCP-L6600DW																				•	•	•						
All-in-one zwart-witlaserprinters MFC				HY			HY		HY		HY		HY		HY					HY	SHY	UHY		HY		HY		
MFC-1810 / 1910W		•																										
MFC-7225N / 7420 / 7820N			•																									
MFC-7320 / 7440N / 7840W				•	•																							
MFC-7360N / 7460DN / 7860DW							•	•																				
MFC-8440 / 8220 / 8840D / 8840DN											•	•																
MFC-8510DW																	•	•										
MFC-8950DW																	•	•	•									
MFC-8820D / 8820DN / 8420																										•	•	
MFC-8860DN / 8870DW / 8460N													•	•														
MFC-8890DW / 8870DN / 8370DN / 8380DN															•	•												
MFC-9050 / 9060 / 9500 / 9550	•																											
MFC-9070 / 9160 / 9180																												
MFC-9650 / 9660 / 9750 / 9760 / 9870 / 9880																							•	•				
MFC-L2700DW / L2720DW / L2740DW									•	•																		
MFC-L5700DN / L5750DW																				•	•							
MFC-L6800DW / L6800DWT																				•	•	•						
MFC-L6900DW / L6900DWT																				•	•	•	•					

* Alle brother laserprinters maken gebruik van gescheiden drum en tonercartridges en zijn los te bestellen. HY= hoge capaciteit cartridge SHY= super hoge capaciteit cartridge UHY= ultra hoge capaciteit cartridge

Drum en tonercartridges voor all-in-one kleurenlaser- en ledprinters DCP / MFC

	*TN-04 BK/C/M/Y	*TN-130 BK/C/M/Y	*TN-135 BK/C/M/Y	DR-130CL	*TN-230 BK/C/M/Y	DR-230CL	*TN-241 BK/C/M/Y	*TN-245 C/M/Y	DR-241CL	*TN-320 BK/C/M/Y	*TN-325 BK/C/M/Y	*TN-328 BK/C/M/Y	DR-320CL	*TN-321 BK/C/M/Y	*TN-326 BK/C/M/Y	*TN-329 BK/C/M/Y	DR-321CL	*TN-900BK/C/M/Y	
All-in-one kleurenlaser- en ledprinters DCP			HY					HY			HY	SHY				HY	SHY		SHY
DCP-9010CN					•	•													
DCP-9015CDW / 9020CDW							•	•	•										
DCP-9040CN / 9042CDN / 9045CDN		•	•	•															
DCP-9055CDN										•	•		•						
DCP-9270CDN										•	•	•	•						
DCP-L8400CDN														•	•			•	
DCP-L8450CDW														•	•	•		•	•
All-in-one kleurenlaser- en ledprinters MFC			HY					HY			HY	SHY				HY	SHY		SHY
MFC-9120CN / 9320CW					•	•													
MFC-9140CDN / 9330CDW / 9440CDW							•	•	•										
MFC-9420CN	•																		
MFC-9440CN / 9450CDN / 9840CDW		•	•	•															
MFC-9460CDN / 9465CDN										•	•		•						
MFC-9970CDW										•	•	•	•						
MFC-L8650CDW														•	•			•	
MFC-L8850CDW														•	•	•		•	•
MFC-L9550CDWT																		•	•

* Alle brother kleurenlaserprinters maken gebruik van vier gescheiden tonercartridges en zijn los te bestellen. BK= zwart C= cyan M= magenta Y= geel HY= hoge capaciteit tonercartridge SHY= super hoge capaciteit tonercartridge